

REVISIONS REV. DESCRIPTION DATE APPRVD.

Notes:

- 1. Noritz recommends the use of Isolation Kit (IK-WV-6) with installation. These kits include an integrated shut-off and service valve with unions and a pressure relief valve.
- 2. Wire aquastat to pump according to "Circulation Pump to Aquastat Wire Diagram (PAWD pdf)." Set the aquastat to 10°F below the set output temperature.
- 3. Size the pump to provide a maximum of 2 GPM through the system at 10 ft of head plus piping losses. Adjust the flow using a globe valve and verify the flow rate with the maintenance
- 4. Size the pump to provide a maximum of 3 GPM with a head pressure equal to the loss through the water heater and Air Handler.
- 5. Expansion tank required if a backflow preventer is installed.
- 6. Check valve required if it is not included with the pump.
- 7. Set the flow switch to deactivate the Air Handler when the domestic hot water flow reaches 3 GPM. Adjust as necessary to prevent cycling.
- 8. If the system requires water for space heating at a higher temperature than for other uses, means such as a mixing valve shall be provided to temper the water for the other uses to help prevent scalding.

Tempered Hot Water for Domestic

NORITZ

11160 Grace Avenue Fountain Valley, California 92630 866-7NORITZ (866-766-7489) www.noritz.com

MODEL.

N-1321M-ASME

APPLICATION:

Hydronic Heating Domestic Hot Water Recirculation Loop Primary Loop

DRAWING NUMBER: (6b1)N1321M DRAWING DATE: September 22, 2008

Noritz Accessories

RC-7649M (Remote Controller)



RC-CORD10 (10' Remote Controller Cord, optional in 26')

VC-132 (Outdoor Vent Cap, place on top of unit)

Note: This diagram is for reference only. Installation must comply with State and Local Code, all gas and water pipe must be sized correctly to specific length, according to accepted engineering methods or the UPC Code for Noritz Water Heaters to operate correctly.





Aquastat (Honeywell Model



Check Valve



Union



Pressure Relief Valve (Watts 174A, Zurn P3000BR, Cash Acme F-82)



#L6006A or L6006C)

Mixing Valve

Pump



Thermal Expansion Tank